

# Instruction Sheet

**Subject: FreshBlender WIFI Connection**


**SCOPE: MULTIPLEX FRESHBLENDERS UI 0.6.9 AND UP**

## WIFI CONNECTION


1. Login to the SERVICE or MANAGER SCREEN.
  - A. This screen is hidden and will require a password. From start screen, touch the three corners in the order shown to access the password screen.
  - B. Type the manager or service password and select ENTER.



2. Select NETWORK.



3. Select WIFI.




4. Verify slider is ON for ENABLE WIFI option.




5. Select SCAN & SELECT.



6. Select SCAN.



7. Select your wifi or hotspot.




8. Enter wifi or hotspot password and select ENTER.




NOTE: In password popup window select SHIFT to turn off/on capital letters.

9. Select CONNECT and wait for screen to automatically return to SERVICE or MANAGER HOME SCREEN.





NOTE: You may be prompted to enter password from Authentication Required popup window. This can happen when password is entered incorrectly.



10. Verify wifi or hotspot is connected.

- A. Select NETWORK.
- B. Select WIFI.
- C. Verify "Connected to" shows wifi or hotspot name.
- D. If "Connected to" shows "off/any" go to STEP 4 and follow steps to connect again.



11. Select BACK/LOGOUT to return to main drink menu.